

Weekend inspiration

Chic desk organiser

You will need:

- 18mm plywood, cut to:
 - one 550mm x 200mm length (for the back),
 - one 550mm x 155mm length (for the base),
 - four 200mm x 130mm dividers
- 6mm x 40mm chipboard screws
- Alcolin Professional Wood Glue
- Alcolin Woodfiller
- 120-grit sandpaper



Instructions:

- 1** Saw a corner of the dividers at a slight angle – this corner will be the front-top corner of the dividers (see the picture alongside). Using Alcolin Professional Wood Glue, glue and screw the dividers to the back plank, spacing them equally apart.
- 2** Turn the structure upside down and glue and screw the base piece on top. Fill any holes with Alcolin Woodfiller, and allow to dry completely before sanding thoroughly.

