

# Protective Knife Rack

**You will need:**

- 22 x 22mm pine, cut into:  
seven 250mm pieces  
seven 150mm pieces
- 22 x 44mm pine, cut into:  
one 300mm piece
- Alcolin Professional Wood Glue
- Panel pins

**Instructions:** Use Alcolin Professional Wood Glue and panel pins to affix the seven 250mm pieces and seven 150mm pieces next to each other along the 300mm piece. Ensure that the ends of the pieces are flush with the edge of the 300mm piece, leaving approximately a 3mm gap between the pieces. A piece of cardboard is ideal here to guarantee consistent spacing.

