

Nifty Couch Caddy

You will need:

- Alcolin Fast Set Wood Glue
- Alcolin Woodfiller (appropriate colour to match the timber)
- Five pieces of 220 x 22mm timber lengths cut according to the dimensions of your armrest: sides (x2), top (x1), ledge (x1), lip (x1)
- 40mm screws
- Paint of choice (optional)

Instructions:

Glue and screw together the pieces of wood using Alcolin Fast Set Wood Glue.

Fill the screw holes with Alcolin Woodfiller and allow to dry before painting.

Stock up on snacks and drinks, and don't forget the remote!

